



OREQA EEC

Tertiary heat recovery unit for false ceiling manual



Instruction manual for installation and maintenance of heat recovery unit for false ceiling OREQA EEC



*Dear customer,
We thank you for purchasing a Casals Ventilación product,
manufactured with first choice materials and advanced technologies.
The quality level is under constant control, and Casals Ventilación products
are therefore synonymous with Safety, Quality and Reliability.*


*Estimado cliente,
Le agradecemos la compra de un producto Casals Ventilación,
fabricados con materiales de primera elección y tecnologías avanzadas.
El nivel de calidad está bajo control constante, y los productos de Casals Ventilación
son por lo tanto sinónimo de Seguridad, Calidad y Fiabilidad.*

Casals Ventilación Air Industrial SL



Read and understand
the instructions before
undertaking any work on
the unit

The Company have the right to introduce at any time whatever modifications necessary to the improvement of the product.



Reproduction, data storage and transmission, even partial, of this publication, in any form, without the prior written authorisation of Casals Ventilación, is prohibited. Casals Ventilación can be contacted for all inquiries regarding the use of its products. Casals Ventilación follows a policy of continuous product development and improvement and reserves the right to modify specifications, equipment and instructions regarding use and maintenance at any time, without notice.

Declaration of conformity (FAC-SIMILE)

We declare under our own responsibility that the units and the equipment complies in all parts with the CEE and EN directives. The CE declaration of conformity is enclosed to the technical schedule enclosed with the unit.

This units has been designed in accordance with the following EU Directives:

- **Directive 2006/42/CE** of the European Parliament and of the Council of May 17th, 2006 on machinery;
- **Directive 2014/35/CE** Low Voltage by achievement of the following technical standards:
EN 60335-2-40:2003 + A11:2004 + A12:2005 + A1:2006 + EC:2006 + A2:2009 + A13:2012 + A13/EC:2013, EN 60335-1:2002 + A11:2004 + A1:2004 + A12:2006 + A2:2006+ A1/EC:2007 + A13:2008 + EC:2009 + EC:2010 + A14:2010 + A15:2011;
- **Directive EMC 2014/30/UE** of the European Parliament and of the Council of February 26th, 2014 on the harmonisation of the laws of the Member States relating to electromagnetic compatibility (recast), by achievement of the following technical standards: EN 60335- 1:2012, EN 55014-1:2006 + A1:2009 + A2:2011, EN 61000-3-2:2006 + A1:2009 + A2:2009, EN 61000-3-3:2013, EN 55014-2:1997 + A1:2001 + A2:2008;
- **Directive RoHS 2011/65/UE**;
- **Directive 2010/30/UE** relating to energy labelling;
- **Directive 2009/125/UE** with implementing regulation D. Lgs. n. 15 of February 16th, 2011 and the following harmonised standard: EN 60204-1:2018



The unit is equipped with a series of prevention and safety devices described in detail in the accompanying documentation. The installer is required to connect and activate all these mounted components, checking their functionality.



The system or machine into which this unit is to be incorporated must also comply with the above mentioned Directives. The user, or whoever subsequently operates the system, must periodically check the functionality and efficiency of the safety devices.




The non-activation, removal or inhibition of the active safety systems, as well as the removal of the passive safety systems, exempt Casals Ventilación from any responsibility regarding any accident or damage, direct or indirect, to people and/or things, attributable to the machine.




The manual supplied with the unit is completed by a TECHNICAL DATA SHEET, with the fundamental constructive and functional data, and by the relative DRAWINGS.



Transport, handling, installation and subsequent operation must be carried out in full compliance with the above prescriptions, in the subsequent indications of the manual and the accompanying documentation.




David Samper Falgàs
Empowered person
CE marking




GENERAL INDEX

1. INTRODUCTION.....	06
1.1 General information.....	06
1.2 Purpose and Content of the Instructions	06
1.3 Storage of instructions	06
1.4 Instructions update	06
1.5 How to use these instructions	06
1.6 Residual Risks	07
1.7 General Safety Symbols.....	09
1.8 Safety Symbols	10
1.9 Limits of use and prohibited uses	11
1.10 Unit identification	11
2. TECHNICAL CHARACTERISTICS.....	12
2.1 Introduction.....	12
2.2 Structure.....	12
2.3 Heat recovery	12
2.4 Air filters	12
2.5 Fans.....	12
2.6 Test	12
2.7 Packing.....	13
3. VERSIONS	13
3.1 Version CONTROL BASIC.....	13
3.2 Version CONTROL COP	13
3.3 Version CONTROL CAV	13
4. CONFIGURATIONS.....	14
4.1 Horizontal configurations "H" (plan view)	14
4.2 Vertical configurations "V" (front view)	14
5. MAIN COMPONENTS OF THE UNIT	15
6. AVAILABLE ACCESSORIES	16
7. OPERATING MODE	18
7.1 Winter operating mode.....	18
7.2 Summer operating mode.....	18
7.3 Free-Cooling operating mode	18
8. TECHNICAL DATA.....	19
9. OPERATING LIMITS.....	20
10. SOUND DATA	21
10.1 Noise levels.....	21
10.2 Sound attenuators reduction	21
11. SAFETY AND CONTROL DEVICES.....	22
12. INSTALLATION	23
12.1 Receipt and inspection.....	24
12.2 Storage	24
12.3 Unpacking.....	24
12.4 Lifting and Handling	25
12.5 Positioning and minimum technical spaces.....	25
12.6 Connecting additional sections: Water coils	27
12.7 Connecting additional sections: Sound attenuators.....	27
12.8 Condensate drain	28
12.8.1 Condensate drain connection (configurations H only).....	28
12.8.2 Condensate drain connection (configurations V only)	28
12.9 Hydraulic connection to the water coil.....	29
12.10 How to vent the unit.....	29
12.11 Connecting the unit to air ducts	30
12.12 Filters and heat exchanger extraction	31



13. RS485 SERIAL INTERFACE CARD.....	32
14. CO2 PROBE (SCO2 IAQ).....	32
15. ELECTRICAL CONNECTIONS	33
15.1 Electrical data	34
15.2 Power supply connection.....	34
15.4 Detail of electrical panel	37
16. STARTUP	37
16.1 Preliminary checks	37
16.2 Description of the controller.....	38
17. UNIT USE	39
17.1 Turn ON the unit and setting parameters.....	39
17.2 Set "Real Time Clock" (RTC)	40
17.3 Set operation by time bands.....	41
17.4 Enable control with CO2 air quality sensor	42
17.5 Enabling reversible mode of the cooling coil.....	43
17.6 Alarms display and reset	44
18. DIAGNOSIS AND TROUBLESHOOTING	45
18.1 Troubleshooting	45
19. DIMENSIONAL DRAWINGS.....	46
20. UNIT MAINTENANCE	50
20.1 General warnings	50
20.2 Access to the unit.....	50
20.3 Periodical checks	50
21. DECOMMISSIONING	51
21.1 Disconnecting the unit	51
21.2 Decommissioning, disposal and recycling	51
21.3 RAEE Directive (EU only)	51



1. INTRODUCTION

Units must be installed and operated according to the instructions in this manual. Strict adherence to these simple instructions is a prerequisite to:

- eliminate or reduce shutdown time due to unexpected failures;
- improve the performance of components, resulting in energy savings;
- increase the life of components and the entire unit;
- decrease maintenance costs.

1.1 General information

This manual has been prepared to allow correct installation, set-up and maintenance of the unit. Any contractual or extra-contractual responsibility of the Company for damage caused to persons, animals or things, due to installation, adjustment and maintenance errors or improper use, is excluded. Any use other than that specified does not imply for the manufacturer any commitment or obligation of any kind.

This documentation is an informative support and cannot be considered as a contract towards third parties.

The Company implements a policy of constant improvement and development of its products. It therefore reserves the right to make changes to specifications, fittings and documentation at any time, without prior notice and without any obligation to update what has already been delivered.

1.2 Purpose and Content of the Instructions

These instructions provide essential information for the installation, operation, testing and maintenance of the machine. They have been drawn up in accordance with the legal provisions issued by the European Union and the technical standards in force at the time the instructions were issued.

The local safety regulations in force at the time of installation must be observed.

The instructions contain instructions for avoiding reasonably foreseeable misuse.

1.3 Storage of instructions

This manual and the eventual wiring diagram of the unit must be carefully stored in a suitable place, protected from dust and humidity and easily accessible to users and operators for any further consultation.

The instructions must always follow the unit throughout its entire life cycle and must therefore be passed on to any subsequent user.

1.4 Instructions update

It is recommended to check that the instructions are up to date with the latest revision available.

Any updates sent to the customer should be retained as an attachment to this manual.

The Company is available to provide any information regarding the use of its products.


1.5 How to use these instructions



The instructions are an integral part of the unit.

It is compulsory for users or operators to consult the instructions before any operation on the unit and on any occasion of uncertainty regarding the transport, handling, installation, maintenance, use and dismantling of the unit.

In these instructions, in order to draw the attention of operators and users to the operations to be carried out in safety, graphic symbols have been included that are shown in the following paragraphs.



1.6 Residual Risks

A residual risk is any hazard that cannot be fully reduced by design and protective techniques, or a potential hazard that is not obvious.



ATTENTION

This manual indicates any operation that may generate a hazardous situation as well as the precautionary measures to be observed in each case.

- All units have pictograms with hazard warnings.
- The units are safe machines, provided the safety guards are not tampered with or removed.
- Technical preparation, observance of the procedures outlined in this manual, and markings at critical points on the unit will still allow safe operation.
- The following safety rules must be observed during installation, start-up, use and maintenance of the units:



- Do not operate the unit unless it and its electrical components have been connected to the earthing system;
- Do not operate unit unless fan is connected to a duct or protected with safety mesh;
- Do not use the unit as a stand for other machinery;
- Do not use unit as a walkway;
- Do not use unit as equipment storage;
- Do not open inspection panels while fan is running, especially in over pressure sections;
- Do not leave inspection panels partially closed; Make sure all handles or knobs are securely closed;



- Wear personal protective equipment before working on the unit;




- Before accessing the unit, make sure that all electrical utilities have been turned off, especially before opening the inspection panels, make sure that the fan is off and cannot be turned on again without the knowledge of the person working on the unit;



- Before starting the fan, always refit the protection cover or the closing panel of the fan section;




- Be careful when lifting the unit as its center of gravity may be severely unbalanced;
- Be careful when locking the lifting ropes/hooks;
- Be careful of sheet metal edges inside the unit;
- Be careful of sheet metal edges outside the unit;
- Be aware of possible burns from heating coils;
- Be aware of dampers that may close unexpectedly.



Whilst the unit has been designed to minimize any risk posed to the safety of people who will interact with it. It has not been technically possible to eliminate completely the causes of risk. It is therefore necessary to refer to the requirements and symbolism below.

LOCATION OF RISK (if present)	RESIDUAL RISK	METHOD OF INJURY	PRECAUTIONS AND PROTECTIONS
Mixing box with dampers and actuators	Crush	Contact	Remove voltage before any operation
Thermal heat exchangers	Small stab wounds, burns	Contact	Avoid any contact, use protective gloves
Electric heaters	Electrocution, severe burns	Contact, Fire due to short circuit or overheating of the heating elements	Periodic check of the safety devices, adhesive warning signs on the machine
Heat exchangers	Small stab wounds, crush	Contact	Avoid any contact, use protective gloves
Fans	Cuts, eye damage, broken bones	Insertion of objects through the fans are operating	Never put objects through the fans sections
External to unit: unit enclosure	Intoxication, severe burns	Fire due to short circuit or overheating of the supply cable external to unit	Size cables and mains protection system in accordance with standards regulations
Internal component: electric cables and metallic parts	Electrocution, severe burns	Defect in the supply cable insulation, live metallic parts	Adequate protection of power cables, ensure correct earthing of all metal parts



1.7 General Safety Symbols

Individual safety symbols in accordance with ISO 3864-2:



PROHIBITION

A black symbol inserted in a red circle with a red diagonal indicates an action that must not be performed.



WARNING

A black graphic symbol within a yellow triangle with black borders indicates a hazard.




MANDATORY ACTION

A white symbol inserted in a blue circle indicates an action that must be performed to avoid a hazard.

Combined safety symbols in accordance with ISO 3864-2:



The graphic symbol "warning" is qualified with additional safety information (text or other symbols).



1.8 Safety Symbols



GENERAL DANGER

Strictly observe all indications placed beside the pictogram. Failure to observe the indications may lead to situations of risk with possible consequent damage to the health of the operator and the user in general.



ELECTRICAL HAZARD

Observe all signs placed next to the pictogram. The symbol indicates components of the unit and actions described in this manual that could create an electrical hazard.



MOVING PARTS

The symbol indicates those moving parts of the unit that could create risk.




SHARP SURFACES

The symbol indicates components or parts that could cause stab wounds.



EARTH CONNECTION

The symbol identifies earthing connection points in the unit.




READ AND UNDERSTAND THE INSTRUCTIONS

Read and understand the instructions of the machine before any operations.



RECOVER OR RECYCLE MATERIAL



1.9 Limits of use and prohibited uses

The machine has been designed and built exclusively for the uses described in the technical manual. Any other use is prohibited as it could generate health risks for the operators and users.



However, the unit is not suitable for operation in environments:

- where vibrations are present;
- where electromagnetic fields are present;
- where aggressive atmospheres are present.







THIS UNIT IS NOT SUITABLE FOR OPERATION IN EXPLOSIVE ATMOSPHERE.

1.10 Unit identification

Each unit has a label attached to the outside of the unit, which shows the identification data of the machine together with the main technical characteristics.

For electrical information not included on the label, refer to the electrical diagram. Check that the characteristics of the electrical network comply with the data on the identification plate.

A FAC-SIMILE of the nameplate is shown below with the relative caption of the data::

		Manufactured by: CASALS VENTILACIÓN AIR INDUSTRIAL S.L.U Ctra. Camprodon, s/n 17860 Sant Joan de les Abadesses (Girona) Spain - Tel. +34 972720150 www.casals.com			
NRVU UNIT MODEL MODELO DE UNIDAD UVNR		1			
POWER SUPPLY FUENTE DE ALIMENTACIÓN		2			
NOMINAL AIR FLOW CAUDAL NOMINAL		3			
EC FAN SUPPLY SIDE LATERAL VENTILADOR EC APORTACIÓN		EC FAN EXHAUST SIDE LATERAL VENTILADOR EC EXTRACCIÓN			
POWER INPUT ENTRADA ALIMENTACIÓN	4	POWER INPUT ENTRADA ALIMENTACIÓN	7		
RATED CURRENT INTENSIDAD NOMINAL	5	RATED CURRENT INTENSIDAD NOMINAL	8		
USEFUL EXT. PRESS. PRESIÓN EXT. ÚTIL	6	USEFUL EXT. PRESS. PRESIÓN EXT. ÚTIL	9		
MAX. ELECTRIC CURRENT MAX. CORRIENTE ELÉCTRICA	10				
MAX. CURRENT WITH ELECTRIC HEATER MAX. CORRIENTE CON CALENTADOR ELÉCTRICO	11				
WEIGHT PESO	12 + 13	 			
MADE IN SPAIN					
SERIAL NUMBER NÚMERO DE SERIE	14	PART CODE CÓDIGO	15		
MANUFACTURED PERIOD PERÍODO DE FABRICACIÓN	16				


CAPTION:

- (1) Unit model and size
- (2) Power supply characteristics
- (3) Nominal air flow
- (4) Electric power input on supply side
- (5) Rated current on supply side
- (6) External static pressure on supply side
- (7) Electric power input on exhaust side
- (8) Rated current on exhaust side
- (9) External static pressure on exhaust side
- (10) Max. electric current consumption
- (11) Max. current consumption with electric heater
- (12) Main unit weight
- (13) Coils add-on module weight
- (14) Serial number
- (15) Unit part code
- (16) Manufactured period

For each support request to the Company it is essential to always quote the model and serial number indicated on this plate (ref. 1 and 14).



The identification label must never be removed from the unit.



2. TECHNICAL CHARACTERISTICS

2.1 Introduction

The sick building syndrome is a disease recognized by the World Health Organization that presents a series of symptoms due to the presence of toxic elements in the workplace. The main sources of pollution originate both from factors inside and outside the building.

Replacing the air, not wasting energy, is the solution. Thanks to the installation of Controlled Mechanical Ventilation systems it is possible to guarantee the correct air exchange and filtration.

The heat recovery units provide the air exchange together with the recovery of a part of the thermal energy of the extracted air which is given to the fresh air at practically no cost; therefore a pre-heating in winter or a pre-cooling in summer of the introduced air is obtained, moreover they bring other advantages such as air filtration and a smaller sizing of the heating and cooling systems, allowing savings both during the purchase and the conduction of the same.

The units are available in 7 sizes, with nominal air flow rates from 400 to 4000 m³/h.

The units in **H1, H2, H3, H4** configurations have been designed for false ceiling installation, while those in **V1, V2, V3, V4** configurations are suitable for floor installation.

All configurations are available in the **CONTROL BASIC**, **COP**, and **CAV** version.

2.2 Structure

Self-supporting structure in sandwich panels with internal insulation made of high density polyurethane foam (40 kg/m³). The panels are 25 mm thick and are made of 6/10" thick steel sheets, the external side is pre-painted RAL 9010, the internal side is hot-dip galvanized Z140. The structure is made according to the EN1886 standard, class D1 mechanical resistance. A particularly adaptable and resilient neoprene gasket guarantee the air tightness. Screws that ensure an adequate and constant pressure on the gaskets fix the opening panels. In all areas subject to condensation is present a condensate drip tray, inclined internally and in compliance with EN 1.4301. All internal components are accessible from below (configurations H) or laterally (configurations V) by means of removable panels in order to guarantee the correct ordinary and extraordinary maintenance.

2.3 Heat recovery

The units are equipped with an aluminium counter-flow heat exchanger used to transfer heat from the exhaust air to the fresh air. The spacing between the fins is optimised in order to reduce air side pressure drop and fan power consumption.

The heat recovery is also equipped with an additional by-pass damper for the management of the free-cooling and free-heating mode as per ERP regulation. By-pass damper 100% of the airflow rate.

2.4 Air filters


ePM₁≥50% (F7) filters in return air and ePM₁≥50% (F7) filters in fresh air. Both types of filters are mounted on slides equipped with gaskets to ensure effective sealing. Their position, upstream of the internal components, also guarantees their protection. Additionally, an ePM₁≥80% (F9) filter can be ordered in discharge.

2.5 Fans

Independently controllable, they consist of aerodynamically balanced, statically and dynamically balanced forward blade centrifugal impellers with aerodynamic profile, made of galvanized steel. The impellers are directly coupled to EC brushless motors, with internal rotor, operating via a 0-10V signal.

2.6 Test

Units are fully assembled and wired at the factory and subjected to a complete functional test before shipment. They are manufactured in compliance with the safety standard of the Machinery Directive 2006/42/EC, the Low Voltage Directive 2006/95/EC, and the Electromagnetic Compatibility Directive 2004/108/EC and therefore complies with the "Health and safety requirements" prescribed. Units are provided with CE markings, certificate of conformity, user and maintenance manual.



2.7 Packing

Units are supplied on thick wooden pallets and wrapped in plastic film to protect against impacts during transport and handling on site.

3. VERSIONS

3.1 Version CONTROL BASIC

BASIC: complete with air temperature sensors installed on the fresh air intake and on room return air. The control allows to select, in stepless mode, the supply and return fan speeds and automatically manages the heat recovery by-pass damper through the motorized On/Off control, summer/winter seasonal change over, and programming for daily time zones. An optional hot water or cold water coil may also be managed, controlled by a 3-way modulating valve through the room return air sensor.

The optional electric post-heating coil is also managed in modulating mode (always via the room return air sensor). The control alerts the user when filters need replacing (the clogged state of the filters is monitored by a pair of differential pressure switches supplied as standard) or the onset of any alarm; this may also be integrated into modern home automation systems via RS485 serial port with Modbus protocol.

3.2 Version CONTROL COP

COP: this control option is set to operate at constant pressure, it is supplied complete with pressure transducer and air temperature sensors installed on the fresh air intake and room return air.

The control system allows to select, in stepless mode, the supply and return fan speeds and automatically manages the heat recovery by-pass damper through the motorized On/Off control.

It also manages the summer/winter seasonal change over and programming for daily time zones.

The control can also manage an optional hot water or cold water coil through a 3-way modulating valve and an additional supply air sensor in order to maintain a fixed point operating logic.

The same logic can also be used to manage an electric post-heating coil, if present. The control alerts the user when filters need replacing (the clogged state of the filters is monitored by a pair of differential pressure switches supplied as standard) or the onset of any alarm; this may also be integrated into modern home automation systems via RS485 serial port with Modbus protocol.

3.3 Version CONTROL CAV

CAV: this control option is set to operate at constant air-flow, it is supplied complete with pressure transducer and air temperature sensors installed on the fresh air intake and room return air.

The control system allows to select, in stepless mode, the supply and return fan speeds and automatically manages the heat recovery by-pass damper through the motorized On/Off control.

It also manages the summer/winter seasonal change over and programming for daily time zones.

The control can also manage an optional hot water or cold water coil through a 3-way modulating valve and an additional supply air sensor in order to maintain a fixed point operating logic.

The same logic can also be used to manage an electric post-heating coil, if present.


The system alerts to the user when filters need replacing (the clogged state of the filters is monitored by a pair of differential pressure switches supplied as standard) or the onset of any alarm and this may also be integrated into modern home automation systems via RS485 serial port with Modbus protocol.

REMTABLE CONTROL PANEL







All units are supplied complete with a remotable control panel with LCD graphic display.

The clean and modern lines and the installation options, panel or wall mounted (with its own power supply or from a controller), make them easy to integrate into any type of environment.








4. CONFIGURATIONS

4.1 Horizontal configurations "H" (plan view)




4.2 Vertical configurations "V" (front view)






5. MAIN COMPONENTS OF THE UNIT



1	Return air filter	7	Electrical panel
2	Counterflow heat exchanger	8	External box for water coils ⁽¹⁾ (heating / cooling)
3	Forward blade centrifugal fan, EC brushless motor with internal rotor (exhaust side)	9	LCD remote graphic display
4	Fresh air inlet filter		
5	By-Pass damper on heat exchanger		
6	Forward blade centrifugal fan, EC brushless motor with internal rotor (supply side)		

⁽¹⁾ component supplied on request as an accessory



6. AVAILABLE ACCESSORIES

Return side $ePM_1 \geq 50\%$ (F7) air filter

Built with a galvanized sheet metal frame and a 48 mm thick pleated filtering sieve, in white fiberglass, contained by two welded galvanized nets. The filter media has an $ePM_1 \geq 50\%$ (F7) filtering degree, according to ISO 16890 and has a large filtering surface area that guarantees long operating life and less frequent replacements.

Supply side $ePM_1 \geq 50\%$ (F7) air filter

Built with a galvanized sheet metal frame and a 48 mm thick pleated filtering sieve, in white fiberglass, contained by two welded galvanized nets. The filter media has an $ePM_1 \geq 50\%$ (F7) filtering degree, according to ISO 16890 and has a large filtering surface area that guarantees long operating life and less frequent replacements.

Return side $ePM_1 \geq 80\%$ (F9) air filter

Built with a galvanized sheet metal frame and a 48 mm thick pleated filtering sieve, in white fiberglass, contained by two welded galvanized nets. The filter media has an $ePM_1 \geq 80\%$ (F9) filtering degree, according to ISO 16890 and has a large filtering surface area that guarantees long operating life and less frequent replacements.

Supply side $ePM_1 \geq 80\%$ (F9) air filter

Built with a galvanized sheet metal frame and a 48 mm thick pleated filtering sieve, in white fiberglass, contained by two welded galvanized nets. The filter media has an $ePM_1 \geq 80\%$ (F9) filtering degree, according to ISO 16890 and has a large filtering surface area that guarantees long operating life and less frequent replacements.

Water control valve

It consists of a kit including the 3-way valve for the control of the water flow, to be combined with the hot and/or cold water coil, and its modulating electric actuator. Connection and fitting devices not included (to be arranged for by the installer). **Hot**

Water coil (external)

The hot water coils are supplied in a dedicated section to be installed in the supply air-flow line. The casing has the same sizes and features of the main unit and it is fixed with a dedicated installation kit supplied with it. The coil is manufactured with copper pipes thickness 0,4 mm and aluminium fins thickness 0,11 mm. The pipes are mechanically expanded in the aluminium fins to increase the thermal exchange rate. On request, it is possible to install coils with different capacities from the standard ones, when previously agreed with the factory.

Cold water coil (external)


The cold water coils are supplied in a dedicated section to be installed in the supply air flow line. The casing has the same sizes and features of the main unit and it will be fixed with a dedicated installation kit supplied with it. The coil is manufactured with copper pipes thickness 0,40 mm and aluminium fins thickness 0,11 mm. The pipes are mechanically expanded in the aluminium fins to increase the thermal exchange rate. On request, it is possible to install coils with thermal performances different from the standard ones, when previously agreed with the factory. The cooling coil section is supplied complete with condensate drain pan with side water discharge.

Defrost system

The automatic defrost system consists of a self-regulating electric coil in PWM mode of the input power, installed on the return air intake. The system is controlled by a special temperature probe positioned on the exhaust air and guarantees a considerable reduction of the input power compared to the traditional systems available on the market.

Electric re-heating coil (internal)

All units may be equipped with an internal re-heating electric coil, made up of armoured steel electric heaters, supplied complete with PWM control system, safety thermostat already wired and installed on board.



Air damper with actuator

This is installed on board the unit and operate to exclude the fresh air intake and/or the room return air flow. This option is particularly useful in areas with very cold winter temperatures, where it is necessary to avoid dangerous self-induced cold air flows by the installation itself, during the stand-by period of the unit, with the risk of freezing the water contained in the water coils, if any. The damper is controlled by On/Off actuator for the opening or the closing, or with return closing spring.

Return side sound attenuator

The sound attenuator consists of a cylindrical section made in galvanized steel sheet, containing a mineral wool sound proofing material covered with glass wool jacket and perforated galvanized steel sheet containment. The soundproofing material is class M0. The construction avoids any risk of mineral wool fraying even at high air speeds. The cylindrical section is fixed to the unit by screws.


supply side sound attenuator

The sound attenuator consists of a cylindrical section made in galvanized steel sheet, containing a mineral wool sound proofing material covered with glass wool jacket and perforated galvanized steel sheet containment. The soundproofing material is class M0. The construction avoids any risk of mineral wool fraying even at high air speeds. The cylindrical section is fixed to the unit by screws.

CO₂ probe

BASIC version units can be equipped with air quality CO₂ probe. This accessory is installed and wired in the factory. If it's installed on the return air duct it allows to determine the quantity of carbon dioxide present in the environment, increasing the quantity of external air to dilute its content.

ATTENTION: The CO₂ probe is not available in COP and CAV versions.




7. OPERATING MODE

7.1 Winter operating mode

The return air from the room, with a higher thermal load than the fresh air, crosses the plate heat exchanger, where it gives up part of its thermal load and cools down before being exhausted. The fresh air, with a lower thermal load than the return one from the room, crosses the plate heat exchanger in the opposite direction and heats up before the introduction into the room. The modulation of the airflow rate, through variation of the rotation speed of the EC fans, will allow a precise control of the supply air temperature. During winter operation, in particular working conditions with low external temperatures, the heat exchanger could be subject to the formation of surface frost with consequent loss of efficiency.


To prevent this from happening, the unit provides for the controlled management of an automatic defrosting cycle, obtained by means of a self-regulated electric battery in PWM mode, installed on the room air intake. The system increases the temperature of the exhaust air thus avoiding the risk of frost on the heat exchanger. The system is controlled by a specific temperature probe positioned on the air outlet and guarantees a considerable reduction of the power absorbed by the unit, compared to the traditional systems on the market.



7.2 Summer operating mode


The return air from the room, with a lower thermal load than the fresh air, crosses the plate heat exchanger, where it takes part of its thermal load and heats up before being exhausted. The fresh air, with a higher thermal load than the room air, crosses the plate heat exchanger in the opposite direction and cools down before the introduction into the room.


The modulation of the airflow rate, by varying the rotation speed of the EC fans, will allow a precise control of the supply air temperature.



7.3 Free-Cooling operating mode

When the outdoor air temperature is lower than the temperature of the room to be air-conditioned and if the latter requires cooling, the unit operates in Free-Cooling mode by opening the By-Pass damper positioned on the plate heat exchanger and thus allowing the entry of outdoor air without heat recovery.





8. TECHNICAL DATA

MODEL		005	006	010	015	020	030	040
Type of ventilation unit		UVNR-B (Non Residential Ventilation Units - Bidirectional)						
Type of drive installed		Analog signal on EC fan (0-10Vdc)						
Type of fans	type/nr.	EC / 2	EC / 2	EC / 4	EC / 2	EC / 2	EC / 2	EC / 2
Type of heat recovery system (HRS)	type/nr.	static counter-flow / 1						
Winter Thermal Efficiency (η_{t_nrvu}) ⁽¹⁾	%	76,4	77,3	76,9	78,5	79,0	75,8	76,7
Winter Thermal Efficiency ⁽²⁾	%	84,4	84,9	84,7	86,0	86,2	83,9	84,5
Nominal airflow rate	m ³ /h	410	650	1000	1620	2150	3040	3980
Electrical power consumption	kW	0,19	0,29	0,49	0,84	1,19	1,27	1,78
Installed electrical power	kW	0,35	0,35	0,70	1,45	1,50	2,20	4,42
SFP _{int}	W/(m ³ /s)	950	670	988	1066	1127	861	994
SFP _{lim} 2018	W/(m ³ /s)	1186	1202	1176	1196	1190	1059	1045
Front speed at design range	m/s	2,18	1,61	2,03	2,14	1,93	2,21	2,41
External nominal pressure $\Delta p_{s, ext}$ ⁽³⁾	Pa	150	150	150	150	150	150	150
Internal pressure drop $\Delta p_{s, int}$ Ret./Supp.	Pa	187/163	117/95	187/157	199/176	190/169	199/174	240/203
Fans static efficiency (UE) n.327/2011	%	33,2	31,9	33,7	31,5	30,1	43,2	43,2
Max. external / internal leakage percentage	%	max 3,5 % at -400 Pa max 5,0 % at +250 Pa						
Energy classification filters		ePM1 \geq 50% (F7) ePM10 \geq 80% (F9)						
Filter pressure switch		present						
Sound power level ⁽⁴⁾	dB(A)	73	74	78	81	82	83	83
Sound pressure level ⁽⁵⁾	dB(A)	59	60	63	66	67	67	67
Power supply	V/ph/Hz	230/1/50					400/3/50	


⁽¹⁾ ratio between the thermal gain of the inlet air (0 °C) and the thermal loss of the exhaust air (20 °C), both referred to the external temperature, measured under dry reference conditions, with balanced mass flow and a thermal difference of the internal/external air of 20K, excluding the thermal gain generated by the fan motors and the internal leakage, in accordance with the provisions of attached V of EU Regulation No 1253/2014

⁽²⁾ outside air: -5 °C / 80 % RH - Inside air: 20 °C / 50 % RH



⁽³⁾ performance with clean filters

⁽⁴⁾ sound power level calculated in accordance with EN 3744

⁽⁵⁾ sound pressure level measured at 1 m free field distance, in accordance with EN 3744



9. OPERATING LIMITS



All units can operate, within the given limits, with room relative humidity in the not exceeding 65%.




It is mandatory to use the units within the operating limits shown in the diagrams above. The warranty will immediately expire if the unit is used in working conditions outside the above limits. If it is necessary to operate in conditions outside the operating range of the unit, please contact our technical department.



The units are designed and built to operate with supply water temperatures ranging from 7°C to 80°C.



Units are designed and built to operate inside false ceilings and/or technical rooms. The units are NOT suitable for outdoor installation as condensation may form on the unit's panels and inside the electrical panel with consequent damage to the unit.



10. SOUND DATA

The noise level of units is basically due to the fan rotation speed.

Obviously, with the same air flow rate, the fan speed will be lower if the required static pressure is low, while it will be higher (and therefore noisier) if the required static pressure is higher.

10.1 Noise levels

The table below shows the sound levels of the units at the nominal working conditions:

MOD.	Nominal air flow m ³ /h	E.s.p. Pa	Octave band (Hz)								Lw	Lp
			63	125	250	500	1K	2K	4K	8K	dB(A)	dB(A)
005	410	150	68	66	64	64	59	56	54	51	73	59
006	650	150	70	68	66	66	61	58	56	53	74	60
010	1000	150	73	72	69	70	64	61	59	56	78	63
015	1620	150	73	74	74	73	70	70	70	67	81	66
020	2150	150	60	70	74	73	78	75	58	52	82	67
030	3040	150	44	63	71	71	81	71	52	45	83	67
040	3980	150	51	68	73	74	81	73	54	46	83	67


Lw: sound power level calculated in accordance with EN 3744

Lp: sound pressure level measured in free field at 1 m from the unit, directionality factor Q=2, according to EN 3744 with ducted unit.

10.2 Sound attenuators reduction

The sound attenuators are of the circular absorption type without baffle. They are suitable for reducing the noise that propagates through the ventilation systems in the aeraulic ducts.

MOD.	Nominal air flow m ³ /h	E.s.p. Pa	Octave band (Hz)							
			63	125	250	500	1K	2K	4K	8K
005	410	150	1	3	5	9	14	10	7	8
006	650	150	1	3	5	9	14	10	7	8
010	1000	150	2	4	6	10	14	10	7	8
015	1620	150	2	4	6	10	14	10	7	8
020	2150	150	2	4	6	10	14	10	7	8
030	3040	150	2	4	6	10	14	10	7	8
040	3980	150	2	4	6	10	14	10	7	8



11. SAFETY AND CONTROL DEVICES

- **Supply air temperature probe**

Passive sensor type NTC 10kΩ. Positioned on the supply air side, downstream of the heating/cooling units, it is used to monitor the temperature of the air supplied to the room. It is installed in combination with the temperature control accessories (water coils or post-heating electric resistance). Through this probe it is also possible to control eventual air delivery temperatures in the environment that are too cold in summer or too hot in winter.

- **Return air temperature probe**

Passive sensor type NTC 10kΩ. Positioned on the room air intake and upstream of the filtering section, its purpose is to monitor the temperature of the air extracted from the room to be treated. Always present in all units, it is used as a control probe of the room temperature set and for the management of the summer free-cooling function.

- **Outdoor air temperature probe (fresh air)**

Passive sensor type NTC 10kΩ. Positioned on the fresh air intake and upstream of the filtering section, it is used for monitoring the temperature of the fresh air entering the heat recovery unit. Always present in all units, it is used in combination with the room air intake temperature probe to manage the summer free-cooling function.

- **Exhaust air temperature probe**

Passive sensor type NTC 10kΩ. Positioned on the air outlet and downstream of the plate heat exchanger, it monitors the temperature of the air exhausted from the unit. It is installed in combination with the defrosting kit with the function of controlling the exhaust temperature of the plate heat exchanger in order to avoid freezing of the same during the winter operation of the unit.

- **Defrost kit**

The defrost system consists of an exhaust air temperature probe and an electrical heater positioned inside the unit on the room return air side, downstream of the filtering section and upstream of the plate heat exchanger. If the temperature downstream of the plate heat exchanger should drop dangerously below the set point and thus avoid the danger of freezing, the electrical heater is activated, which, through a power modulation control (with PWM signal), heats the air extracted from the room and consequently increases the exhaust temperature.

In this way, the ice formation on the exchanger plates is avoided. The power modulation control allows a considerable energy saving thanks to the fact that the electrical energy absorbed by the electric heater is just the one strictly necessary to bring the unit back to optimal working conditions.

- **Unbalanced airflows defrost system**

The defrost system (optional) consists of a specific device and software that avoid an excessive drop of the exhaust air temperature slowing down the supply and return airflow and, in case the opening of the by-pass damper.

This system is normally supplied in combination with the hot water coil (optional).


- **Differential pressure switch**

This component is used to monitor the clogging status of the air filters. There are two pressure switches for each unit, one installed on the fresh air filter section and one located on the room return air filter section. If one of the filters has a pressure difference greater than the recommended limit, an alarm is displayed on the user interface.

- **Differential pressure transducer**

Active type transducer with 4-20mA current output signal. It is installed only in the TOP and PLUS versions and positioned in the electrical panel. In the TOP versions it is connected with the pressure socket available on the supply fan, the purpose is to keep the constant flow rate set by the user.

In the PLUS versions, one pressure tap measures the static pressure at the supply outlet, the other one measures the atmospheric pressure. The aim is keeping the constant supply static pressure. This type of regulation leads to a VAV (Variable air Volume) system that can be used in those applications where a heat recovery unit serves several rooms.



12. INSTALLATION

General warnings and use of symbols



Before carrying out any type of operation, each operator must be perfectly familiar with the operation of the machine and its controls and must have read and understood all the information contained in this manual.



All operations performed on the machine must be carried out by qualified personnel in compliance with the national legislation in force in the country of destination.



Installation and maintenance of the machine must be performed in compliance with applicable national or local legislation.



Do not approach or insert any object into moving parts.

Workers' Health and Safety



The operator's workstation must be kept clean, tidy, and free of objects that may restrict free movement. The workplace should be adequately lightened for the intended operations. Insufficient or excessive lighting may present a hazard.



Ensure that the ventilation of the working areas is always optimal and that the extraction systems are always functional, in good condition and in compliance with the legal requirements.

Personal protection devices



Operators carrying out installation and maintenance of the machine must wear the legally required individual protective equipment listed below.



Safety footwear.




Eye protection.



Protective gloves.



Hearing protection.



12.1 Receipt and inspection

When installing or working on the unit, it is necessary to scrupulously follow the instructions given in this manual, observe the indications on board the unit and in any case apply all necessary precautions. Failure to follow these instructions may result in dangerous situations.

Upon receipt of the unit, check its integrity: the machine left the factory in perfect condition; any damage must be immediately reported to the carrier and noted on the Delivery Note before signing it.

The Company must be informed, within 8 days, about the extent of the damage. The Client must fill out a written report in case of significant damage.

Before accepting the delivery check:

- that the unit has not been damaged during transport;
- that the material delivered corresponds to what is indicated in the transport document.

In case of damages or anomalies:

- immediately note the damage on the Delivery Note;
- inform the supplier, within 8 days of receipt, of the extent of the damage. Reports made after this deadline are not valid;
- in the event of significant damage, file a written report.

12.2 Storage

If it is necessary to store the unit, leave it packed in a closed place. If for some reason the machine has already been unpacked, follow the instructions below to prevent damage, corrosion and/or deterioration:

- make sure all openings are properly plugged or sealed;
- do not use steam or other cleaning agents to clean the unit, as these may damage it;
- remove any keys used to access the control panel and give them to the site manager.

12.3 Unpacking




Packaging material (plastic film, expanded polystyrene, etc.) must be kept out of the reach of children as a potential hazard.

It is advisable to leave the units packed during handling and to remove the packaging only at the time of installation. Remove the packaging of the unit with care to avoid possible damage to the machine.

The materials making up the packaging can be of different kinds (wood, cardboard, nylon, etc.). It is advisable to remove the protective film from the panels (if present) after the installation of the unit.



Packaging materials should be stored separately and handed over for disposal or recycling to the appropriate.




12.4 Lifting and Handling


When unloading and positioning the unit, care must be taken to avoid sudden or violent manoeuvres to protect internal components. Lifting should be done using a forklift or alternatively using straps, taking care not to damage the side and top panels of the unit.

The length of the forks must be adequate for the length of the section to be handled in order to avoid the risk of tipping over and/or damaging the bottom of the unit.

During handling and transport, sections must remain in position as packed at the factory, and absolutely no tipping or tilting should be done.



CONFIGURATION H




CONFIGURATION V

12.5 Positioning and minimum technical spaces

The drawing below shows the false ceiling installation (H configurations), where the unit is suspended using brackets. The brackets must be connected to the vibration dampers, selected according to the type of structure they are fixed to. In units with an H configuration, the siphon is not installed (at the factory), but must be installed on site by the customer. It is necessary to provide one or more openings in the false ceiling for the removing and subsequent cleaning of air filters, maintenance and control of the electrical panel.


CONFIGURATION H (FALSE CEILING INSTALLATION)



MOD.	A	B	C
005	500	500	120
006	500	500	120
010	500	500	120
015	500	500	120
020	500	500	120
030	500	500	120
040	500	500	120


CAPTION:

1. Ceiling | 2. Side walls | 3. Removable false ceiling



The drawing below shows the installation with floor installation (V configuration), where the unit is placed on the ground on its own baseframe, in which the appropriate siphon has already been installed (at the factory). The following minimum measures must be observed in order to guarantee the extraction and subsequent cleaning of the air filters, maintenance and control of the electrical panel.

CONFIGURATION V (FLOOR INSTALLATION)



MOD.	D	E
005	600	500
006	600	500
010	600	500
015	600	500
020	600	500
030	--	--
040	--	--

CAPTION:


1. Ceiling | 2. Side walls



Install the unit to allow ordinary and extraordinary maintenance. The warranty does not cover costs related to platforms or handling equipment necessary for any intervention.





Choose the installation site in accordance with EN 378-1 and 378-3.



12.6 Connecting additional sections: Water coils

To connect additional sections containing water coils, proceed as follows:

- locate the opening of the unit on which to attach the section;
- apply the sealing gasket supplied with the unit, on the contact perimeter between the base unit and the additional box;
- approach the additional box to the base unit centering it on the fan mouth;



- using the brackets, if present, support the box so that its weight does not weigh on the unit;
- fix the module with the screws provided.




CAUTION: Do not remove any other screws / panels during this operation.




For box equipped with ceiling mounting brackets, do not lift the unit with the box attached. The box must be supported using the brackets provided.

12.7 Connecting additional sections: Sound attenuators

The sound attenuators are fastened with the screws provided between the edge at the end of the sound attenuator and the circular connection of the unit. The other end will be fixed, again with the supplied screws, to the circular duct.




Provide brackets to hold the sound attenuator and ductwork in order to prevent their weight from bearing on the unit.



12.8 Condensate drain

12.8.1 Condensate drain connection (configurations H only)

The connection to the condensate drain, for the units with horizontal configuration (H), must be carried out on site by the customer, through a rigid pipe attached to the 1/2" F external diameter fitting located on the side panel of the unit. A siphon sized for the maximum vacuum inside the unit must be installed on the condensate drain pipe.



Example:

If the unit has 220 Pa of external static pressure, the total height (A+B) of the siphon (Hsf) in mm is:

$$H_{sf} = A + B = 70 + (1.5 \times (220/10)) = 103 \text{ mm}$$


$$B = 1.5 \times C \text{ where } C = 22 \text{ mm}$$




Each drain must be independent and have its own siphon.
The lack of a siphon may affect the proper operation of the unit.

12.8.2 Condensate drain connection (configurations V only)


The condensate drain, for units with a vertical configuration (V), is positioned in the bottom side of the unit with the appropriate siphon already installed in the factory. The connection to the siphon must be carried out on site by the customer, through a rigid pipe attached to the 1/2" F external diameter fitting located on the side of the integrated baseframe of the unit.





12.9 Hydraulic connection to the water coil

For a correct hydraulic connection to the water coil and to the relative modulating 3-way valve, proceed as shown in the diagram below:



GENERAL RULES

- Respect the IN/OUT adhesive references on the side of the unit;
- The path of the pipes must be assessed so as not to create particular obstacles in case of removal of the coil;
- The piping must be supported by specific brackets in order to prevent their weight from bearing on the unit;
- The interposition of flexible joints is strongly recommended in order to avoid the transmission of vibrations and noise;
- During installation the hydraulic connections of the coil must be protected from twisting by locking;
- For proper operation of the equipment, it is recommended to supply the unit with a dedicated pump and to vent the circuit using the appropriate vent valves on the coil manifold.


12.10 How to vent the unit


For a proper functioning of the system, it is essential to remove the air from the hydraulic circuit.

To vent the coil, proceed as follows:


- unscrew the fastening screws of the dedicated panel of the external box;
- remove the panel;
- use the vent valve located on the internal manifold of the coil.

After venting the unit, close the panel with the screws.






12.11 Connecting the unit to air ducts



Fixing of air ducts on CIRCULAR connections
on supply and return air




Fixing of air ducts on RECTANGULAR connections
on supply and return air

GENERAL RULES


For a correct installation of the ductwork it is recommended to:

- design the duct so that the air speed never exceeds 4-5 m/s, for the purpose of noise containment;
- provide suitable brackets to support the ducting to prevent their weight from bearing on the unit;
- always use a flexible joint between the unit and the ductwork;
- provide an electrical earth cable to bridge the flexible joint, to ensure the duct and the unit are electrically equipotential;
- before bends and branches, provide a straight duct with a length equal to at least 2.5 times the shorter side (or diameter) of the duct to avoid drops in fan performance.




12.12 Filters and heat exchanger extraction


In order to remove the filters, it is necessary to unscrew the dedicated panels as shown in the picture here below.



In order to remove the heat recovery unit, it is necessary to unscrew the dedicated panels as shown in the picture here below.



Do not use water to clean the plate heat recovery unit. It is however possible to vacuum the rear part of the heat exchanger after removing it, as shown on the picture.



13. RS485 SERIAL INTERFACE CARD



Serial line interface card to the supervision system (available only MODBUS-RS485). The installation of the card will allow the unit to be connected to a system with MODBUS-RS485 protocol.

This system allows you to remotely monitor all the operating parameters of the unit and change their values. The serial interface card is installed and wired exclusively in the factory.

The unit does not work in case of inversion of the polarity of the wiring. The unit is programmed with serial address 1. The list of MODBUS variables is available by contacting the company.

14. CO₂ PROBE (SCO₂ IAQ)

The Casals CO₂ air quality probe (SCO₂ IAQ) can only be available for BASIC configuration units. It must be installed outside the unit, on the return room intake. The probe measures the carbon dioxide amount present in the room, according to the value it will increase (or decrease) the fresh air volume so that the presence of CO₂ will be diluted.



TECHNICAL DATA

Temperature sensor:

- Sensor type: NTC.
- Measuring range: 0.0°C to 50.0°C.
- Sensor life: >10 years.

RH sensor:


- Sensor type: capacitive with integrated electronic circuit.
- Measurement range: 0% to 100%.
- Sensor life: >10 years.

CO₂ (carbon dioxide) sensor:

- Sensor type: NDIR (Non-Dispersive Infrared detector). Dual sensor.
- Measurement range: 0ppm to 2000ppm.
- Sensor life: >5 years.
- Note: factory calibrated sensors. CO₂ sensors calibration function.

Functions:

- Control function of the start/stop of the air purifier/Fan by means of digital output by voltage-free relay contact.
- Regulation function on the CO₂ of a fan with EC technology or a damper with 0-10V signal.
- Hourly and daily programming with two time slots per day available.



- Environmental measurements of temperature, relative humidity and CO₂
- 0... 10V analog outputs for environmental measurements.
- CO₂ Measurement range: 0ppm to 2000ppm 0ppm: 0.0V ... 2000ppm:10.0V
- Electrical supply voltage: 100... 250V
- Modbus serial communication channel for integration in centralized systems (BMS).
- Mounting in an indoor environment. Mounting base prepared for universal mechanism box.
- Easy connection: Plug & Play.

15. ELECTRICAL CONNECTIONS

Preliminary safety information



The electrical connection must be made according to the wiring diagram enclosed with the unit and in compliance with local and international regulations.



Make sure the disconnecter of the unit power supply line is upstream the unit. Ensure it is padlocked or that the appropriate warning is present indicating not to operate.



Check that the power supply corresponds to the rated data of the unit (voltage, phases, frequency) shown on the wiring diagram and on the nameplate attached to the unit.



Power supply cables must be protected upstream against electric short-circuit and overload by a suitable device complying with current standards and laws.



The cross-section of the cables must be suitable for the calibration of the upstream protection system and must take into account all factors that may affect it (temperature, type of insulation, length, etc.)



The warranty will be void if the power supply does not comply with the above limits.



Make all earthing connections required by current standards and legislation.




Make sure to disconnect the power supply before beginning any operation.



FROST PROTECTION:

when open, the main switch excludes the electric power to the heating elements and any antifreeze device in the unit. Open the main switch only for cleaning, maintenance or repair of the unit.



15.1 Electrical data



The following electrical data refer to the basic unit without accessories.
In all other cases, refer to the electrical data in the wiring diagram attached to the unit.



The supply voltage must not vary more than $\pm 10\%$ of the nominal value and the unbalance between phases must be less than 1% according to EN 60204.
Please contact our technical department in case these tolerances are not respected.


MODEL		005	006	010	015	020	030	040
Power supply	V/Ph/Hz	230/1/50	230/1/50	230/1/50	230/1/50	230/1/50	400/3+N/50	400/3+N/50
Control circuit		12 VDC / 24 VAC						




Electrical data may change without notice. Therefore, ALWAYS refer to the wiring diagram supplied with the unit.

15.2 Power supply connection

Remove the front panel of the electrical cabinet with the appropriate tool; use the cable gland on the side panel of the cabinet and connect the power supply cable inside the electrical cabinet to the disconnecting switch with fuses. After making the connection, carefully close the front panel of the electrical cabinet.






15.3 Terminal Block Connections



Terminal numbers may change without notice. ALWAYS refer to the wiring diagram supplied with the unit.

All the terminals shown in the following tables are in the terminal block inside the electrical cabinet, all the electrical connections mentioned below must be made in the field by the installer.




SINGLE-PHASE POWER SUPPLY

It is used to power supply the unit with single-phase system

(mod. 005 - 006 - 010 - 015 - 020).

The power cable should be connected directly to the fuses or to the electric coil mainswitch.

The earth terminal is present (PE).




THREE-PHASE POWER SUPPLY

It is used to power supply the unit with three-phase system

(mod. 030 - 040).

The power cable should be connected directly to the fuses or to the electric coil mainswitch.

The earth terminal is present (PE).




REMOTE ON/OFF

It is used to turn on/off the unit from a remote device.

The units are supplied as standard from the factory with jumpered terminals.

Closed contact: unit is ON;

Open contact: unit is OFF.




FIRE/SMOKE ALARM

It is used to turn off the unit from an external fire control unit.

The units are supplied as standard from the factory with jumpered terminals.

Closed contact: no unit alarm works;

Open contact: alarm from external fire control unit. The unit stops.



REMOTE DISPLAY FOR CONTROL

D2 - EPJ Graph


00 connect to terminal VAC- of the display;

4.8 connect to terminal VAC+ of the display;


5.4 connect to terminal CAN+ of the display;

5.5 connect to terminal CAN- of the display;

The remote display is only suitable for indoor use, it cannot be installed in areas with strong vibrations, aggressive/corrosive agents, very dirty or high humidity.




REMOTE DISPLAY FOR CONTROL D2 - EPJ Graph




- 00 connect to terminal VAC- of the display;
- 4.8 connect to terminal VAC+ of the display;
- 5.4 connect to terminal CAN+ of the display;
- 5.5 connect to terminal CAN- of the display;

The remote display is only suitable for indoor use, it cannot be installed in areas with strong vibrations, aggressive/corrosive agents, very dirty or high humidity.



MODBUS RS-485 CONNECTION


- 5.3 connect the negative pole (-) of the ModBus network;
 - 5.2 connect the positive pole (+) of the ModBus network;
 - 5.1 connect the GND of the ModBus network;
- allows connection to a supervisory system (BMS) via ModBus RTU communication protocol on RS-485 serial line



WATER COIL PUMP CONTROL

Control by voltage-free contact, which sends a consent to the external water pump, if present:


- accessory A: cooling coil;
- accessory B: heating coil.



REMOTE GENERAL ALARM


For remote signalling of a general alarm.
Voltage-free contact.

Contacts 6.5 / 6.6 NO (Normally Open)




3-WAY VALVE ACTUATOR (HEATING COIL)

- 00 e 24 power supply of the valve actuator;
- 7.4 0-10V control signal from PLC card;




3-WAY VALVE ACTUATOR (COOLING COIL)

- 00 e 24 power supply of the valve actuator;
- 7.5 0-10V control signal from PLC card;



15.4 Detail of electrical panel



16. STARTUP

16.1 Preliminary checks

It is necessary to carry out preliminary checks on the electrical and hydraulic parts before starting the unit.



Perform the commissioning operations in accordance with all the requirements of the previous paragraphs.




Malfunctions or damage may also result from lack of proper care during shipment and installation. It is good practice to check before installation or commissioning that there are no damages due to tampering, vibration during transport, mistreatment suffered on site.

- Check that the machine is installed in a state of the art manner and in accordance with the instructions in this manual.
- Check electrical connection and correct fastening of all terminals.
- Check that the voltage is as indicated on the unit's rating plate.
- Check that the unit is connected to the earth system.
- Check that there are no leakages.
- Check that the hydraulic connections have been installed correctly and that all indications on the nameplate are respected.
- Check that the system has been properly vented.
- Check that fluid temperatures are within operating limits.
- Before turning the unit on, check that all closing panels are in place and secured with the appropriate screws.










Do not modify the internal electrical connections as this will immediately invalidate the warranty.




16.2 Description of the controller

FUNCTION OF KEYS AND DISPLAY ICONS



KEY	FUNCTION
	<ul style="list-style-type: none"> • press and hold will turn on or turn off the device • press and hold will reset the alarms with manual reset • while setting the parameters, it has the function of “Back” key • a simple pressure from main screen allows the access to the alarm page
	<ul style="list-style-type: none"> • a simple pressure allows to move within the status pages
	<ul style="list-style-type: none"> • a simple pressure allows to move on a superior menu during the menu navigation • a simple pressure allows to increase one unit the value of the variable. Specific variable edit mode should be activated
	<ul style="list-style-type: none"> • a simple pressure allows to move on an inferior menu during the menu navigation • a simple pressure allows to decrease one unit the value of the variable. Specific variable edit mode should be activated
	<ul style="list-style-type: none"> • a simple pressure allows to move within the status pages
	<ul style="list-style-type: none"> • press and hold allows to enter and exit the settings menu • a simple pressure allows to change the parameter value and set-point and confirm it while it is set to “edit” (blinking) • during the menu navigation, it has the function of “Enter” key



17. UNIT USE

17.1 Turn ON the unit and setting parameters

UNIT START

21/09/2020 13:43	
26.6°C	KEY

| |
PRESS AND HOLD

Once the unit is powered and the main-switch is activated, the display turns ON and shows a screen similar to the one you can see above, i.e. unit turned off by KEY. From this screen, it is necessary to press and hold the "ON/STAND-BY" key in order to activate the unit.

MAIN SCREEN

21/09/2020 13:43	
26.6°C	

| OK |
PRESS AND HOLD

When the unit starts, from this screen it is possible to access to all the menu following explained, through press and hold of the "OK" key.

USER MENU

MENU		
USER	TIME BANDS	MAINTENANCE
INSTALLATION	RTC	ALARMS
Pag. 1/2		Next >

| OK |

Access to the USER menu does not require a password. In this menu there are all the parameters that the user can freely modify. Press the "OK" key to access.

SET LANGUAGE INTERFACE

USER MENU	
FSN:	40 %
DSC:	20 %
DSE:	20 %
DSN:	20 %
PF40:	35.0
PF42:	35.0
LNG:	English
PSd1:	0

| OK |
| ^ |
| v |

Using the "UP" or "DOWN" keys, navigate to the LNG parameter and select the value "English" or another language. Confirm the value entered with the "OK" key.

OPERATING MODE

USER MENU	
MODE:	Summer
SETC:	24.0 °C
SETH:	20.0 °C
PU01:	55 %
SCC:	24.0 °C
SCH:	21.0 °C
OEC:	0.0 °C
OEH:	0.0 °C

| v |

To change the operation mode, use the "UP" or "DOWN" keys and navigate to the MODE parameter. Select the desired value according to the required operation mode of the unit.

Summer = COOLING MODE | **Winter** = HEATING MODE

SUMMER SET-POINT

USER MENU	
MODE:	Summer
SETC:	24.0 °C
SETH:	20.0 °C
PU01:	55 %
SCC:	24.0 °C
SCH:	21.0 °C
OEC:	0.0 °C
OEH:	0.0 °C

| v |

To change the summer set-point:

- press the "OK" key, the value blinks;
- press the "UP" or "DOWN" keys to change the parameter;
- confirm with "OK" key.


WINTER SET-POINT

USER MENU	
MODE:	Winter
SETC:	0.0 °C
SETH:	4.0 °C
PU01:	0 %
SCC:	0.0 °C
SCH:	4.0 °C
OEC:	0.0 °C
OEH:	0.0 °C

| v |

To change the winter set-point:

- press the "OK" key, the value blinks;
- press the "UP" or "DOWN" keys to change the parameter;
- confirm with "OK" key.



CONSTANT FLOW AND PRESSURE SETTING

USER MENU		
FSN:	40	%
DSC:	20	%
DSE:	20	%
DSN:	20	%
PF40:	35.0	
PF42:	35.0	
LNG:	English	
PSd1:	0	



[PLUS Vers.] SET-POINT CONSTANT PRESSURE (Pa x10)
[TOP Vers.] SET-POINT CONSTANT FLOW RATE (m³/min)

Parameter PF40 relates to supply air, while PF42 is the parameter relating to return air.

To change the parameter:

- press the "OK" key, the value blinks;
- press the "UP" or "DOWN" keys to change the parameter;
- confirm with "OK" key.

AIR-FLOW SETTING [ECO VERSION]

21/09/2020 13:43		
26.6°C	☀	☞
☞		



[ECO Vers.] SETTING AIR-FLOW RATE

From the main screen:

- press the "UP" or "DOWN" keys to increase/decrease the rotation speed of the fans.

USER MENU PASSWORD

USER MENU		
FSN:	40	%
DSC:	20	%
DSE:	20	%
DSN:	20	%
PF40:	35.0	
PF42:	35.0	
LNG:	English	
PSd1:	0	



USER MENU PASSWORD

(0 = PSW not required for the access)

To change the parameter:

- press the "OK" key, the value blinks;
- press the "UP" or "DOWN" keys to change the parameter;
- confirm with the "OK" key.

17.2 Set "Real Time Clock" (RTC)

CLOCK SETTINGS

21/09/2020 13:43		
26.6°C	☀	☞
☞		



In the event of a prolonged power failure, it may be necessary to reset the unit's RTC clock ("ALARM 29").

From the main screen, through press and hold of the "OK" key, the USER MENU is accessible.

RTC MENU

MENU		
USER	TIME BANDS	MAINTENANCE
INSTALLATOR	MANUFACT.	RTC
Pag. 1/2		Next >



Then select the RTC icon and press the "OK" key to access.

DATE / TIME


SETTING RTC		
21/09/2020 13:43		




To change the date and time:

- press the "OK" key, the value blinks;
- press the "UP" or "DOWN" keys to change the parameter;
- press the "LEFT" or "RIGHT" keys to move from one parameter to another;

Once the setting is complete, press the "OK" key to confirm the entered values. Press the "ON/STAND-BY" key twice to return to the main screen.




17.3 Set operation by time bands



With the unit in operation / switched off, press and hold the "OK" key to access to the user menu screen.

Then select the *TIME BANDS* icon and press the "OK" key to access.




The cursor is positioned on the item *Enable*:

- press the "OK" key, the value blinks;
- press the "UP" key to enable the time bands;

To set the time bands, go to *Setting*:

- press the "OK" key to access to the setting menu for the day MONDAY.




To set values in *B1*, *B2*, *B3*, *B4* bands:

- press the "OK" key, the value blinks;
 - press the "UP" or "DOWN" keys to change the parameter;
- The available options are: "Off" "Comfort" "Economy" "Night".
- confirm the parameters with the "OK" key.

To change the start times of the *B1*, *B2*, *B3*, *B4* bands:

- press the "OK" key, the value blinks;
- press the "UP" or "DOWN" keys to change the parameter;
- press the "LEFT" or "RIGHT" keys to move from one parameter to another;
- confirm the parameters with the "OK" key.




To change to a previous / next day:

- press the "LEFT" or "RIGHT" keys to change the day;


To set time bands on all other days, follow the same procedure as described before.

To copy time bands from one day to another, use the "Copy from ..." button.



It is possible to set *Unit ON/Unit OFF* mode for a period of absence. This mode is activated from the moment of setting.

From the *TIME BANDS* menu, select the *Holiday* item using the "DOWN" key and confirm with the "OK" key.



To set the *Holiday* mode:


- press the "OK" key, the value of days/hours blinks;
- press the "UP" or "DOWN" keys to change the parameter;
- confirm with the "OK" key.

To set the *Unit ON/OFF* mode, follow the same procedure as described before.


In the *HOLIDAY END* field, set the day and time when the programmed holiday period ends.

Selecting the *START HOLIDAY* field and pressing the "OK" button the holiday mode start immediately.


To deactivate this mode, set the *PERIOD* values to 0 and confirm with the "OK" key on *START HOLIDAY*.




17.4 Enable control with CO2 air quality sensor




If the unit is ON, switch it OFF. Connect the CO₂ sensor as shown in the circuit diagram. From the main screen, through press and hold of the "OK" key, the MENU is accessible.



Select the MANUFACTURER icon and press the "OK" key to access.




Then select the FANS icon and press the "OK" key to access.



MANUFACTURER MENU PASSWORD = 43


To change the parameter:

- press the "OK" key, the value blinks;
- press the "UP" or "DOWN" keys to change the parameter;
- confirm with the "OK" key.




Using the "UP" or "DOWN" keys, navigate to the PF01 parameter and select the value "AQ mod."


Confirm the value entered with the "OK" key.



The air flow rate depending on the level of CO₂ in the room. The parameters PF19 and PF20 set the min/max PPM limits. Default values are 500/1100 ppm, within which the ventilation varies from min flow rate of 30% to max flow rate of 100%.




From the MANUFACTURER menu, select the HARDWARE icon and press the "OK" key to access.




If required, enter the MANUFACTURER PASSWORD = 43


Using the "UP" or "DOWN" keys, navigate to parameter HA03, select the value "17" and confirm with the "OK" key. Press the "ON/STAND-BY" key several times to return to the main screen and then restart the unit.




17.5 Enabling reversible mode of the cooling coil




If the unit is ON, switch it OFF. From the main screen, through press and hold of the "OK" key, the MENU is accessible.



Select the MANUFACTURER icon and press the "OK" key to access.




Then select the CONFIGURATION icon and press the "OK" key to access.



MANUFACTURER MENU PASSWORD = 43

To change the parameter:

- press the "OK" key, the value blinks;
- press the "UP" or "DOWN" keys to change the parameter;
- confirm with the "OK" key.




Using the "UP" or "DOWN" keys, navigate to the PG04 parameter and select the value "Mix". Confirm the value entered with the "OK" key.

Press the "ON/STAND-BY" key several times to return to the main screen.


CAUTION !!!

This procedure is valid ONLY to enable heating operation of a cooling coil and NOT VICEVERSA.

The company accepts no responsibility if the user enables cooling operation of a heating coil, as this does not have a condensate drain pan, which would cause water to be present inside the unit.




17.6 Alarms display and reset




When an alarm is triggered requiring the immediate **STOP** of the unit, the unit automatically turn OFF, the blinking "**BELL**" icon appear on the screen, and the corresponding LED blinks on the left side of the controller.


From the main screen, press the "**ON / STAND-BY**" key (simple pressure) to have access to the ALARM PAGE.




Pressing the "**OK**" key alarms will be displayed.



If there are no alarms, the "**NO ALARM**" screen is displayed.



If there are several active alarms, they can be displayed in sequence by pressing the "**UP**" or "**DOWN**" keys.




To reset an alarm, is enough to press the "**OK**" key on it.

Once reset all the alarms, the blinking icon of the "**RED BELL**" disappears and "**NO ALARM**" screen is displayed.

To go back to the main screen press the "**ON / STAND-BY**" key (simple pressure).



ATTENTION: automatic reset alarms reset themselves once the cause of the alarm has been removed.



18. DIAGNOSIS AND TROUBLESHOOTING

18.1 Troubleshooting


All units are checked and tested at the factory before delivery, however, it is possible that some anomaly or failure may occur during operation.



It is recommended to reset an identification alarm only after removing the cause that generated it; repeated resets may result in irreversible damage to the unit.





CODE	ALARM DESCRIPTION	RESET	CONSEQUENCE
AL07	Heater overheating alarm	Manual	Turns off all the heaters and forces the fans to 100%
AL08	Air filter pressure switch	Manual	Display only
AL13	Fire/smoke alarm ⁽¹⁾	Automatic	Turns off all devices
AL18	Ambient/return air sensor faulty or disconnected	Automatic	Disables regulations that depends on it
AL19	Supply air sensor faulty or disconnected	Automatic	Disables regulations that depends on it
AL20	Outdoor air sensor faulty or disconnected	Automatic	Disables regulations that depends on it
AL22	Exhaust air sensor faulty or disconnected	Automatic	Disables regulations that depends on it
AL23	Duct pressure sensor faulty or disconnected	Automatic	Disables regulations that depends on it
AL24	Air quality sensor faulty or disconnected	Automatic	Disables regulations that depends on it
AL28	I/O configuration error	Automatic	Turns off all devices
AL29	RTC faulty or disconnected	Automatic	Disabled time band management

⁽¹⁾ These alarms cause the turn off of the unit, putting it on the OFF by alarm status.



19. DIMENSIONAL DRAWINGS

CONFIGURATION H (mod. 005-006-010-015-020)




Due to the large number of configurations available, only general dimensional drawings are shown, which are to be considered purely indicative and may change without notice. The specific drawing of the ordered unit is present in the documents supplied with the unit itself.





GENERAL DIMENSIONAL DATA

MOD.	A	B	C	D	E	F	G	H	I	L	M	N	Ø	Ø IN	Ø OUT	Ø SC	Weight*
	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[inch]	[inch]	[inch]	[kg]
005	1250	700	340	288	335	316	176	208	159	180	76	173	150	1/2" M	1/2" M	1/2" F	89
006	1350	1000	380	288	455	478	276	246	184	230	71	173	200	1/2" M	1/2" M	1/2" F	108
010	1350	1300	380	288	535	629	283	388	198	230	71	203	250	3/4" M	3/4" M	1/2" F	138
015	1600	1300	500	288	555	629	326	345	250	355	70	223	250	3/4" M	3/4" M	1/2" F	172
020	1600	1550	500	288	675	733	346	471	250	355	70	223	250	3/4" M	3/4" M	1/2" F	212

* Weight is referred to the main unit (without accessories)



CONFIGURATION H (mod. 030)




Due to the large number of configurations available, only general dimensional drawings are shown, which are to be considered purely indicative and may change without notice. The specific drawing of the ordered unit is present in the documents supplied with the unit itself.


GENERAL DIMENSIONAL DATA

MOD.	A	B	C	D	E	F	G	H	I	L	M	N	P x Q	Ø IN	Ø OUT	Ø SC	Weight*
	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[inch]	[inch]	[inch]	[kg]
030	1900	1650	580	288	735	540	190	396	79	430	70	323	262 x 282	3/4" M	3/4" M	1/2" F	284
040	1900	1900	580	288	935	600	282	362	78	430	70	323	262 x 282	3/4" M	3/4" M	1/2" F	354

* Weight is referred to the main unit (without accessories)



CONFIGURATION H (mod. 040)




Due to the large number of configurations available, only general dimensional drawings are shown, which are to be considered purely indicative and may change without notice. The specific drawing of the ordered unit is present in the documents supplied with the unit itself.


GENERAL DIMENSIONAL DATA

MOD.	A	B	C	D	E	F	G	H	I	ØL	M	N	O	P	ØIN	ØOUT	W.*
	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[inches]	[inches]	[Kg]
040	1900	1900	580	288	98	150	445	930	525	315	955	445	525	167.5	3/4" M	3/4" M	354

* Weight is referred to the main unit (without accessories)



CONFIGURATION V
(mod. 005-006-010-015-020)




Due to the large number of configurations available, only general dimensional drawings are shown, which are to be considered purely indicative and may change without notice. The specific drawing of the ordered unit is present in the documents supplied with the unit itself.

GENERAL DIMENSIONAL DATA

MOD.	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]	G [mm]	H [mm]	I [mm]	L [mm]	M [mm]	N [mm]	Ø [mm]	Ø IN [inch]	Ø OUT [inch]	Ø SC [inch]	WEIGHT [kg]
005	1250	340	772	288	335	316	176	280	159	42	167	444	150	1/2" M	1/2" M	1/2" F	92
006	1350	380	1072	288	455	478	276	318	184	42	167	472	200	1/2" M	1/2" M	1/2" F	112
010	1350	380	1372	288	535	629	283	460	198	42	167	459	250	3/4" M	3/4" M	1/2" F	142
015	1600	500	1372	288	555	629	326	417	250	42	167	562	250	3/4" M	3/4" M	1/2" F	178
020	1600	500	1622	288	675	733	346	543	250	42	167	562	250	3/4" M	3/4" M	1/2" F	218

* Weight is referred to the main unit (without accessories)



20. UNIT MAINTENANCE

20.1 General warnings

Maintenance allows you to:

- Keep the unit efficient.
- Prevent possible breakdowns.
- Reduce the rate of deterioration of the unit.



It is advisable to provide a unit booklet with the purpose of keeping track of the interventions carried out on the unit, facilitating the potential search for faults.



The maintenance operations must be carried out in compliance with all the prescriptions of the previous paragraphs.



Use personal protective equipment as required by current regulations.

20.2 Access to the unit

Access to the unit once it has been installed must be allowed only to authorised operators and technicians. The owner of the machine is the legal representative of the company, body or natural person who owns the plant where the machine is installed. He is responsible for observing all the safety rules indicated in this manual and in the regulations in force.

20.3 Periodical checks



Commissioning operations must be carried out in accordance with all the requirements of the previous paragraphs.




All operations performed on the unit must be carried out by qualified personnel in compliance with the national legislation in force in the country of destination.

Every 6 months

It is good practice to carry out periodic checks to ensure that the unit, control and safety devices are functioning correctly.

- Check that the electrical terminals inside the electrical cabinet are secure.
- Periodically clean the mobile and fixed contacts of the contactors.
- Check that there are no water leakages in the hydraulic circuit..
- Check the condition of the finned coils, if necessary clean with compressed air in the opposite direction to the air flow. If the coil is completely clogged, clean it with a low-pressure cleaner, taking care not to damage the aluminium fins..
- Check the attachment and balance of the fans.



Unit shutdown

In case of long period shutdown, the hydraulic circuit must be drained so that there is no more water in the pipes and the exchanger. This operation is compulsory if, during the shutdown period, the ambient temperature can fall below the freezing point of the mixture used (typical seasonal operation).

21. DECOMMISSIONING

21.1 Disconnecting the unit



All decommissioning operations must be carried out by authorised personnel in accordance with the national legislation in force in the country of destination.

- Avoid spillage or leakage into the environment.
 - Before disconnecting the unit, recover any brine mixtures from the hydraulic circuit;
- Pending decommissioning and disposal, the machine can also be stored outdoors, provided that the unit has the electrical and hydraulic circuits intact and closed.


21.2 Decommissioning, disposal and recycling

The structure and the various components, if unusable, must be dismantled and sorted according to their nature. All materials must be recovered or disposed of in accordance with the relevant national regulations.

21.3 RAEE Directive (EU only)




- The RAEE Directive requires that the disposal and recycling of electrical and electronic equipment must be managed through a specific collection, in appropriate centres, separate from mixed urban waste.
- The user is obliged not to dispose of the equipment, at the end of its working life, as urban waste, but to comply with Directive 2012/19/EU at European level and with Legislative Decree 49/2014 at national level.
- Units covered by the RAEE Directive are identified by the symbol shown above.
- Manufacturer can supply additional information on request, in particular it will indicate the reference certification body according to RAEE.



NOTES / NOTAS

[illegible]



NOTES / NOTAS

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



Casals Ventilación se reserva el derecho a hacer cambios en los productos para su mejora en cualquier momento sin previo aviso.
Casals Ventilación si riserva il diritto di apportare tutte le varianti migliorative ai prodotti in corso di vendita.
Casals Ventilación reserves the right to make improvements to products at any time and without prior notice.
Casals Ventilación se réserve le droit d'apporter toutes les variations afin d'améliorer ses produits en cours de commercialisation.
Casals Ventilación behält sich vor, alle eventuellen Verbesserungsänderungen an den Produkten des Verkaufsangebots vorzunehmen.
Casals Ventilación 公司 股份有限公司 保留在产品销售期间进行产品改良的权利。

VORTICE GROUP COMPANIES / SOCIEDADES DEL GRUPO VORTICE

VORTICE S.P.A

Strada Cerca, 2
Frazione di Zoate
20067 Tribiano
(Milan) Italy
Tel. (+39) 02 906991
Fax (+39) 02 90699625
vortice.com

VORTICE LIMITED

Beeches House-Eastern
Avenue Burton upon Trent
DE13 0BB United Kingdom
Tel. (+44) 1283 492949
Fax (+44) 1283 544121
vortice.ltd.uk

VORTICE INDUSTRIAL S.R.L.

Via B. Brugnoli 3,
37063 Isola della Scala
(Verona) Italy
Tel. (+39) 045 6631042
Fax (+39) 045 6631039
vorticeindustrial.com

CASALS VENTILACIÓN AIR INDUSTRIAL S.L.

Ctra. Camprodon, s/n 17860
Sant Joan de les
Abadesses
(Girona) Spain
Tel. (+34) 972720150
casals.com

VORTICE LATAM S.A.

Bodega #6
Zona Franca Este Alajuela,
Alajuela 20101
Costa Rica
Tel. (+506) 2201 6934
vortice-latam.com

VORTICE VENTILATION SYSTEM

(Changzhou) Co.LTD
No. 388 West Huanghe Road
Building 19, Changzhou
Post Code: 213000 China
Tel. (+86) 0519 88990150
Fax (+86) 0519 88990151
vortice-china.com

The descriptions and illustrations in this catalogue are intended to be indicative and not binding. Without prejudice to the essential characteristics of the products described and illustrated here, CASALS VENTILACIÓN reserves the right to make, at any time and without notice, changes to parts, aesthetic details or supply of accessories to its products that are deemed to be appropriate for improvement or for any construction or commercial requirement.

This printout completely cancels and replaces all the previous ones.

Las descripciones e ilustraciones de este catálogo tienen carácter indicativo y no vinculante. Sin perjuicio de las características esenciales de los productos aquí descritos e ilustrados, CASALS VENTILACIÓN se reserva el derecho de efectuar, en cualquier momento y sin previo aviso, modificaciones de piezas, detalles estéticos o suministro de accesorios a sus productos que se estimen convenientes para su mejora o para cualquier requerimiento de construcción o comercial.

Esta impresión anula y reemplaza por completo a todas las anteriores.